

BASIS—The total clearing time-current characteristic curves shown above are applicable over the entire Fault Fiter Electronic Power Fuse operating temperature range of -40°C to +55°C. No adjustments need be made to these curves for ambient temperatures within this temperature range, or to reflect self-heating due to the flow of load current.

TOLERANCES—Curves are plotted to maximum test points; all variations are minus.

APPLICATION—The maximum continuous current-carrying capability of S&C Fault Fiter Electronic Power Fuses is 600 amperes rms, regardless of the control module selected.

Since Fault Fiter time-current characteristics are electronically derived, they are not subject to change due to aging, transient overcurrents, or fault currents. It is, therefore, unnecessary to replace Fault Fiter Control Modules following a fault-clearing operation only blown Fault Fiter Interrupting Modules need be replaced. IMPORTANT—S&C Fault Fiter Electronic Power Fuse Control Modules must be selected by qualified persons who are knowledgeable in the subjects of euipment protection and time-current coordination, and who understand the consequences of improperly coordinated overcurrent protective devices. Failure to achieve complete coordination between Fault Fiter Electronic Power Fuses and source-side or load-side protective devices may result in improper operation of one or more Fault Fiter Fuses.

New Publication

5, / C ©2002



S&C ELECTRIC COMPANY

Page 1 of 1 September 9, 2002